

Disclaimer: Installing an aftermarket radio in your **Acura MDX** will result in the loss of your factory rear entertainment, dvd player, factory hands free link and external cd changer. You will also lose the factory navigation audio prompts. Your navigation touchscreen will still work. The steering wheel controls that work with the aftermarket radio are volume up, volume down, next track, previous track and mode. The call buttons will not work with the aftermarket radio nor will the navigation prompt buttons on the steering wheel. Additional parts may be necessary to keep your factory steering wheel controls depending on the radio you are installing.

Notice: When replacing the radio in your Acura MDX if you have a 2001, 2002, 2003 or 2004 there is only one connector that will need to be wired to your aftermarket radio. If you have a 2005 or 2006 Acura MDX with navigation then 3 connectors must be wired. If your 2005 2006 Acura MDX doesn't have navigation then you will only need two connectors. To complete the installation you must color match all the wires to your aftermarket radio harness.

Blue 20 Pin for BOSE system Connector A Blue 20 Pin for NON-BOSE Connector A (All Years)

PIN	COLOR	FUNCTION
A1	Yellow	Constant 12V+
A3	White (RCA)	FL+ RCA
A4	Red (RCA)	FR+ RCA
A5	White (RCA)	RL+ RCA
A6	Red (RCA)	RR+ RCA
A8	Gray	Steering Wheel Control Output (All Years)
A9	Red	Switched 12V+
A10	Blue	Amplifier Turn On
A11	Black	Ground
A12	Orange	Illumination Output 12V+
A13	Black (RCA)	FL- RCA
A14	Black (RCA)	FR+ RCA
A15	Black (RCA)	RL+ RCA
A16	Black (RCA)	RR+ RCA
A20	Black	Steering Wheel Control Ground (05-06 Only)

PIN	COLOR	FUNCTION
A1	Yellow	Constant 12V+
A3	White	FL+
A4	Grey	FR+
A5	Green	RL+
A6	Purple	RR+
A8	Gray	Steering Wheel Control Output (All Years)
A9	Red	Switched 12V+
A10	Blue	Antenna Power
A11	Black	Ground
A12	Orange	Illumination Output 12V+
A13	White/Black	FL-
A14	Gray/Black	FR-
A15	Green/Black	RL-
A16	Purple/Black	RR-
A20	Black	Steering Wheel Control Ground (05-06 Only)

Gray 2 Pin Connector D (05-06 Only)

Pin	Color	Function
D2	Black	Antenna Signal AM/FM
D3	Blue	Antenna Power Input 12V+

White 14 Pin Connector B (05-06 Only)

Pin	Color	Function
B9	Blue Twisted	GA-NET+ Resistor Loop
B10	Red Twisted	GA-NET+ Resistor Loop

Pioneer/Kenwood/Sony: Most Pioneer, Kenwood, and Sony radios only have one blue/white wire. This **blue/white wire must be connected** to the blue wires on the connectors provided in our wiring otherwise you will have no sound. If you are having trouble please call or text 877-542-2872