

Disclaimer: The steering wheel controls that work with the aftermarket radio are volume up, volume down, next track, previous track and mode. Additional parts may be necessary to keep your factory steering wheel controls depending on the radio you are installing.

Notice: These DIY instructions are only meant for Honda Civics without navigation and with or without the premium sound system. To complete the installation you must color match all the wires to your aftermarket radio harness. The **blue/white wire of your aftermarket radio must be connected** to the blue/white wire on the 20 pin connector otherwise you will have no sound. If you are having trouble please call or text 877-542-2872.

Gray 17 Pin Connector A (Premium Sound)

PIN	COLOR	FUNCTION
A2	Black (RCA)	RL RCA -
A3	Black (RCA)	FL RCA -
A7	Black (RCA)	FR RCA -
A8	Black (RCA)	RR RCA -
A9	Black	Ground
A10	Orange	Illumination 12V+ Output
A11	Green (RCA)	RL RCA +
A12	White (RCA)	FL RCA +
A14	Red	Switched 12V+ Output
A15	Gray (RCA)	FR RCA +
A16	Purple	RR RCA +
A17	Yellow	Constant 12V+ Output

Gray 17 Pin Connector A (BASE)

PIN	COLOR	FUNCTION
A2	Green/Black	RL -
A3	White/Black	FL -
A7	Gray/Black	FR -
A8	Purple/Black	RR-
A9	Black	Ground
A10	Orange	Illumination 12V+ Output
A11	Green	RL +
A12	White	FL+
A14	Red	Switched 12V+ Output
A15	Gray	FR +
A16	Purple	RR+
A17	Yellow	Constant 12V+ Output

Dark Gray 20 PIN Connector B

PIN	COLOR	FUNCTION
B5	Blac (RCA)	AUX Input Ground
B6	Gray/Black	Steering Wheel Control Ground
B7	Gray	Steering Wheel Control Output
B13	White (RCA)	AUX Input L
B14	Red (RCA)	AUX Input R
B16	Blue/White	Factory Amplifier Turn On 12V+ Input

Gray 2 Pin Connector C

Pin	Color	Function
D2	Black	Antenna Signal AM/FM
D3	Blue	Antenna Power Input 12V+